

3-Axis RF Meter Quick Start Guide

This meter has many capabilities, including memory, alarm, date/time, average etc. which will require some study of the manual to use properly. However, you can quickly and easily begin making measurements right out of the box. Just follow these simple steps:

- 1- insert 9V battery
- 2- turn meter on with GREEN button
- 3- press XYX/MEM button until all three (XYZ) letters are displayed on the screen (to the left of the main number
- 4- press UNIT/ENTER button until the desired units are displayed below the main number (we recommend using mV/m... and we recommend a maximum level of 600 mV/m for prolonged exposure)

You are now ready to make your first measurements!